

# SIGWM | SENTERA WI-FI INTERNET GATEWAY FOR SURFACE MOUNTING

Mounting and operating instructions



# Table of contents

<b>SAFETY AND PRECAUTIONS</b>	<b>3</b>
<b>PRODUCT DESCRIPTION</b>	<b>4</b>
<b>ARTICLE CODE</b>	<b>4</b>
<b>INTENDED AREA OF USE</b>	<b>4</b>
<b>TECHNICAL DATA</b>	<b>4</b>
<b>STANDARDS</b>	<b>4</b>
<b>WIRING AND CONNECTIONS</b>	<b>5</b>
<b>MOUNTING &amp; OPERATING INSTRUCTIONS IN STEPS</b>	<b>5</b>
<b>VERIFICATION OF INSTALLATION INSTRUCTIONS</b>	<b>8</b>
<b>TROUBLESHOOTING</b>	<b>9</b>
<b>TRANSPORT AND STORAGE</b>	<b>9</b>
<b>WARRANTY AND RESTRICTIONS</b>	<b>9</b>
<b>MAINTENANCE</b>	<b>9</b>

## SAFETY AND PRECAUTIONS

---



Read all the information in this manual, in the datasheet and in the Modbus Register Map before working with the product. For personal and equipment safety and for optimum product performance, make sure you fully understand the content before installing, using or servicing this product.



For safety and licensing (CE) reasons, unauthorised conversions and / or modifications of the product are inadmissible.



The product should not be exposed to abnormal conditions, such as extreme temperatures, direct sunlight or vibrations. Long-term exposure to chemical vapours in high concentration can affect the product performance. Make sure the work environment is as dry as possible and avoid condensation.



All installations must comply with local health and safety regulations and local electrical standards and approved codes. This product should only be installed by an engineer or a technician with expert knowledge of the product and safety precautions.



Avoid contact with energised electrical parts. Always disconnect the power supply before connecting, servicing or repairing the product.



Always check that you are connecting the correct power supply to the product and use wires of the correct characteristics and cross-section. Make sure all screws and nuts are properly tightened and fuses (if any) are in place.



Consideration should be given to recycling the equipment and packaging. These should be disposed of in accordance with local and national laws and regulations.



If there are questions that are not answered, contact your technical support or consult a professional.

## PRODUCT DESCRIPTION

SIGWM is an internet gateway to connect a stand-alone Sentera device or a network of devices to the Internet in order to configure or monitor them via SenteraWeb. SIGWM allows wireless connection to an existing Wi-Fi network. The device has 2 Modbus RTU channels - a Master channel to communicate with the connected Slave devices, and a Slave channel to make the unit accessible for a Master controller or a BMS.

## ARTICLE CODE

Code	Supply	Imax
<b>SIGWM</b>	24 VDC (PoM)	300 mA

## INTENDED AREA OF USE

- Connect your HVAC installation to the online SenteraWeb portal
- Gateway for application dedicated firmware and/or standard firmware updates via SenteraWeb
- Update setpoints, ranges and other parameters in the connected Sentera slave devices
- Data monitoring and data logging via SenteraWeb
- Receive warnings and notifications (e.g. clogged filter notification, motor failure alarm, etc.)

## TECHNICAL DATA

- 24 VDC supply voltage, via Power over Modbus (PoM)
- RJ45-socket (RS485) for Modbus communication (RS-485) with connected devices and PoM supply voltage
- Modbus communication via 3SMCenter suite with additional [CNVT-USB-RS485-V2](#) converter (updating and checking Modbus registers)
- Gateway for transmission to and from the Internet via Wi-Fi
- Firmware updates over SenteraWeb portal
- Built-in Wi-Fi module
- Backup battery for real time clock, in case the power supply is interrupted
- Operating ambient conditions:
  - ▶ Temperature: -10—60 °C
  - ▶ Relative humidity: 5—95 % rH (non-condensing)
- Enclosure: plastic ABS, UL94-V0, grey RAL 7035
- Protection class: IP65

## STANDARDS

- EMC directive 2014/30/EU: CE
  - ▶ EN 61326-1:2013 Electrical equipment for measurement, control and laboratory use - EMC requirements - Part 1: General requirements
  - ▶ EN 55011:2016 Industrial, scientific and medical equipment - Radio-frequency disturbance characteristics - Limits and methods of measurement Amendment A1:2017 and A11:2020 to EN 55011:2016
  - ▶ EN 55024:2010 Information technology equipment - Immunity characteristics - Limits and methods of measurement
  - ▶ EN 50561-1:2013 Power line communication apparatus used in low-voltage installations - Radio disturbance characteristics - Limits and methods of measurement - Part 1: Apparatus for in-home use Amendment AC:2015 to EN 50561-1:2013

- LVD directive 2014/35/EU:
  - ▶ EN 60950-1:2006 Information technology equipment - Safety - Part 1: General requirements Amendments AC:2011, A11:2009, A12:2011, A1:2010 and A2:2013 to EN 60950-1
  - ▶ EN 62311:2008 Assessment of electronic and electrical equipment related to human exposure restrictions for electromagnetic fields (0 Hz - 300 GHz)
- Radio equipment directive 2014/53/EU:
  - ▶ EN 300 328 V2.1.1 Wideband transmission systems; Data transmission equipment operating in the 2,4 GHz ISM band and using wide band modulation techniques; Harmonised Standard covering the essential requirements of article 3.2 of Directive 2014/53/EU
- ETSI EN 301 489-1 V2.1.1 (2017-02) ElectroMagnetic Compatibility (EMC) standard for radio equipment and services; Part 1: Common technical requirements; Harmonised Standard covering the essential requirements of article 3.1(b) of Directive 2014/53/EU and the essential requirements of article 6 of Directive 2014/30/EU
- ETSI EN 301 489-17 V3.1.1 (2017-02) ElectroMagnetic Compatibility (EMC) standard for radio equipment and services; Part 17: Specific conditions for Broadband Data Transmission Systems; Harmonised Standard covering the essential requirements of article 3.1(b) of Directive 2014/53/EU
- RoHS Directive 2011/65/EU:
  - ▶ EN IEC 63000:2018 Technical documentation for the assessment of electrical and electronic products with respect to the restriction of hazardous substances

## WIRING AND CONNECTIONS


RJ45 socket (Power over Modbus)		
Pin 1	24 VDC	Supply voltage
Pin 2		
Pin 3	A	Modbus RTU communication, signal A
Pin 4		
Pin 5	/B	Modbus RTU communication, signal /B
Pin 6		
Pin 7	GND	Ground, supply voltage
Pin 8		

## MOUNTING & OPERATING INSTRUCTIONS IN STEPS

Before you start mounting the unit, read carefully **“Safety and Precautions”** and follow these steps:


1. Mount the unit on a smooth surface through the special openings. Mind the correct position and mounting dimensions shown in **Fig. 1 Mounting dimensions**.

**Fig. 1 Mounting dimensions**



2. Connect the (Sentera) slave devices and 24 VDC via Power over Modbus to the RJ45 socket (see **"Wiring and connections"**).



**Fig. 2 Wiring**



- 3. The red LED lights up to indicate that the unit is supplied, but there is no Wi-Fi connection.
- 4. Consult the User Guide, available on the Sentera website to connect the unit to the Wi-Fi network and to SenteraWeb.

**Optional settings**

If your unit starts or terminates the network (see **Example 1** and **Example 2**), enable the NBT resistor via 3SModbus. If your device is not an end device, leave the NBT disabled (default Modbus setting).



**NOTE**

Connect the NBT terminator only in the two most distant units on the network line!

**Firmware update**

New functionalities are made available via the firmware update of the device. In case your device does not have the latest firmware installed, it can be updated through the SenteraWeb cloud platform. To initiate this procedure, just click on the "Firmware Update" button, available in the relevant Modbus register of the device on [www.senteraweb.com](http://www.senteraweb.com). After that, the unit will be automatically updated.

 **NOTE**


*Make sure the power supply does not get interrupted during "bootload" procedure, otherwise you risk losing unsaved data.*

**Tact switch**

Press and hold the tact switch for at least 5 seconds to reset the unit to its default values:

- default Connection mode: DHCP
- default Modbus communication parameters: 19200 Bps, 8 bits, even parity, 1 stop bit (8,E,1)
- default gateway host page: 192.168.1.123

**Fig. 4 Tact switch**



**Reset buttons**


**1. Left button - for Wi-Fi reset**

In case of connection problems or in order to clean the memory of the Wi-Fi module, press and hold for 2 to 3 seconds until the blue LED (LED2) lights up (see **Fig. 5**). After this, the password inside the memory (to connect to a Wi-Fi Access point) has been erased and the default IP address 192.168.1.123 is restored. Now you can restart the installation procedure as explained in the User Guide that can be downloaded from the Sentera Website.

**2. Right button - for developers only!**

The 'Program' button (see **Fig. 5**) is only needed to restart the microcontroller of the unit for development or debug purposes, such as to enter bootloader mode to reprogram the module. You should NOT press this button in any other cases!

**Fig. 5 Wi-Fi reset tact switch**



## VERIFICATION OF INSTALLATION INSTRUCTIONS

---

- Green LED1 indicates that the unit is supplied and connected to SenteraWeb via the internet.
- Green LED2 blinking indicates active communication with the Internet. i.e. the unit successfully communicates with SenteraWeb sending/receiving parameters to/from the Cloud.
- Green LED2 slowly blinking indicates that bootloader mode has been entered.
- Slowly blinking red LED3 indicates system error (connection to the Cloud has been lost).
- Blinking LEDs on the RJ45 sockets indicate that packages are transmitted via Modbus RTU.
- If this is not the case, check the connections.

**Fig. 5 LED indications**



### ATTENTION

*The status of the LEDs can be checked only when the unit is energised. Take the relevant safety measures!*



## TROUBLESHOOTING

---

### In case of faulty operation, please, check if:

- Check for any serious damages on the enclosure of the gateway or burnt wires, such as RJ45 or Ethernet cables, power supply cables.
- Check the connections. If necessary, rearrange the wires.
- The Wi-Fi connection is stable. When there's no Internet available or it's unstable, you cannot connect the devices, using the Internet gateway.
- Check other devices. Sometimes, the devices, you want to connect are broken or work poorly and must be changed with new ones.

## TRANSPORT AND STORAGE

---

Avoid shocks and extreme conditions; stock in original packing.

## WARRANTY AND RESTRICTIONS

---

Two years from the delivery date against defects in manufacturing. Any modifications or alterations to the product after the date of publication relieve the manufacturer of any responsibilities. The manufacturer bears no responsibility for any misprints or mistakes in this data.

## MAINTENANCE

---

In normal conditions this product is maintenance-free. If soiled, clean with a dry or damp cloth. In case of heavy pollution, clean with a non-aggressive product. In these circumstances the unit should be disconnected from the supply. Pay attention that no fluids enter the unit. Only reconnect it to the supply when it is completely dry.