



RCTHX-2 Intelligent temperature and humidity room sensor

The RCTHX-2 are intelligent room sensors featuring adjustable temperature and relative humidity ranges. The used algorithm controls a single analogue / modulating output based on the measured temperature and humidity values, which can be used to directly control an EC fan, an AC fan speed controller or an actuator powered damper. All parameters are accessible via Modbus RTU.

Key	features	

- Spring contact terminals
- Selectable temperature and relative humidity ranges
- Fan speed control based on temperature and relative humidity
- Bootloader for updating the firmware via Modbus RTU communication
- \bullet Ambient light sensor with adjustable 'active' and 'standby' level
- Modbus RTU communication
- 3 LEDs with adjustable light intensity for status indication
- Long-term stability and accuracy

	Тес	hnical specifications	
Analogue / modulating output	$0-10$ VDC mode: $R_L \ge 50 \text{ k}\Omega$		
	$0-20$ mA mode: $R_{L} \leq 500 \Omega$		
	PWM (open-collector type) mode: 1 kHz, R $_{L} \ge 50~k\Omega,$ PWM voltage level: 3,3 VDC or 12 VDC		
Typical range of use	Temperature range	0-50 °C	
	Relative humidity range	0-95 % rH (non-condensing)	
Accuracy	± 0,4 °C (range 0-50 °C)		
Accuracy	± 3% rH (range 0-100 %)		
Protection standard		IP30 (according to EN 60529)	

		Article codes
Article code	Supply	Imax
RCTHF-2	18—34 VDC	40 mA
RCTHG-2	18—34 VDC / 15—24 VAC ±10 %	40 mA/ 45 mA

Area of use


- Demand controlled ventilation based on measured temperature and relative humidity
- Suitable for residential and commercial buildings
- For indoor use only

		Wiring and	connections
Article type	RCTHF-2	RCTHG-2	
VIN	18-34 VDC	18-34 VDC	15-24 VAC ±10%
GND	Ground	Common ground	AC ~
Α	Modbus RTU (RS485), signal A		
/B	Modbus RTU (RS485), signal /B		
A01	Analogue / modulating output 1 (0 -10 VDC / 0 -20 mA / PWM)		
GND	Ground AO1 Common ground		
Connections	Spring contact terminal blocks, cable cross section: 1,5 mm ²		

Attention! The -G version is intended for 3-wire connection and features a 'common ground'. This means that the ground of the analogue output is internally connected with the ground of the power supply.

The -F version is suited for 4-wire connection. It features separate grounds for power supply and analogue output. Never connect the separated ground of the -F article to other devices powered by an AC voltage. Doing so might cause permanent damage to the device!






1 - Red LED	On	Measured temperature or relative humidity values are out of range
	Blinking	Communication with one of the sensors fails
	On	Measured temperature or relative humidity values are in the alert range
2 - Yellow LED	Blinking	Modbus communication has stopped and HR8 is activated (Modbus timeout > 0 seconds)
3 - Green LED	On	Measured temperature or relative humidity values are within range
4 - Ambient light sensor	0	Low light intensity / Active / Standby
5 - PROG header, P1	1 2 3 4 5	Put a jumper onto pins 1 and 2 and wait for at least 5 seconds to reset the Modbus communication parameters
		Put a jumper onto pins 3 and 4 and restart the power supply to enter bootloader mode


Note: By default, the LED indicators visualise the measured temperature level. When the sensor is in bootloader mode, the green and yellow LEDs flash alternately. During the firmware download, the red LED is flashing additionally.




RCTHX-2 Intelligent temperature and humidity room sensor



Note: The output changes automatically depending on the highest of the T and rH values, i.e. the highest of the two output values controls the output. See the green line in the operational diagram above. One or multiple sensors can be deactivated. E.g. it is also possible to control the output based on the measured temperature only.





How to configure

Via a Sentera Internet Gateway you can connect your installation to the SenteraWeb HVAC cloud and: - Easily change the parameter settings of the connected devices remotely

- Define users and give them access to monitor the installation via a standard web browser
- Log data create diagrams and export logged data - Receive alerts or warnings when measured values
- exceed alert ranges or when errors occur - Create different regimes for your ventilation system -
- e.g. day-night regime

Please refer to the Modbus Register Map of the product for more details regarding the Modbus registers.

Standards

CE

Low Voltage Directive 2014/35/EU:

-EN 60529:1991 Degrees of protection provided by enclosures (IP Code). Amendment AC:1993 to EN 60529 EN 60730-1:2011 Automatic electrical controls for household and similar use -Part 1: General requirements

SenteraWeb


• EMC directive 2014/30/EU: -EN 60730-1:2011 Automatic electrical controls for household and similar use -Part 1: General requirements

EN 61000-6-1:2007 Electromagnetic compatibility (EMC) - Part 6-1: Generic -EN 61000-6-1:2007 Electromagnetic compatibility (EMC) - Part 6-1: Generic standards - Immunity for residential, commercial and light-industrial environments EN 61000-6-3:2007 Electromagnetic compatibility (EMC) - Part 6-3: Generic standards - Emission standard for residential, commercial and light-industrial environments Amendments A1:2011 and AC:2012 to EN 61000-6-3 - EN 61326-1:2013 Electrical equipment for measurement, control and laboratory use EMC standards resident and representation and laboratory

use - EMC requirements - Part 1: General requirements -EN 61326-2-3:2013 Electrical equipment for measurement, control and laboratory

use - EMC requirements - Part 2-3: Particular requirements. Test configuration, operational conditions and performance criteria for transducers with integrated or remote signal conditioning

- WEEE Directive 2012/19/EU
- RoHs Directive 2011/65/EU





RCTHX-2 Intelligent temperature and humidity room sensor



Global trade item numbers (GTIN)		
Packaging	RCTHF-2	RCTHG-2
Unit	05401003017920	05401003017937
Carton	05401003302514	05401003302521
Box	05401003503652	05401003503669

S.1.1.T.10